

Technical data

Ratings

By type designation, the table below provides ratings for the ACS550 adjustable speed AC drive, including:

- IEC ratings
- NEMA ratings (shaded columns)
- frame size.

Ratings, 208...240 V drives

Abbreviated column headers are described in section [Symbols](#) on page 279.

Type ACS550-x1- see below	Normal use			Heavy-duty use			Frame size
	I_{2N} A	P_N kW	P_N hp	I_{2hd} A	P_{hd} kW	P_{hd} hp	
Three-phase supply voltage, 208...240 V							
-04A6-2	4.6	0.75	1	3.5	0.55	0.75	R1
-06A6-2	6.6	1.1	1.5	4.6	0.75	1	R1
-07A5-2	7.5	1.5	2	6.6	1.1	1.5	R1
-012A-2	11.8	2.2	3	7.5	1.5	2	R1
-017A-2	16.7	4	5	11.8	2.2	3	R1
-024A-2	24.2	5.5	7.5	16.7	4	5	R2
-031A-2	30.8	7.5	10	24.2	5.5	7.5	R2
-046A-2	46.2	11	15	30.8	7.5	10	R3
-059A-2	59.4	15	20	46.2	11	15	R3
-075A-2	74.8	18.5	25	59.4	15	20	R4
-088A-2	88.0	22	30	74.8	18.5	25	R4
-114A-2	114	30	40	88.0	22	30	R4
-143A-2	143	37	50	114	30	40	R6
-178A-2	178	45	60	150	37	50	R6
-221A-2	221	55	75	178	45	60	R6
-248A-2	248	75	100	192	55	75	R6

00467918.xls C

Ratings, 380...480 V drives

Abbreviated column headers are described in section [Symbols](#) on page 279.

Type ACS550-x1- see below	Normal use			Heavy-duty use			Frame size
	I_{2N} A	P_N kW	P_N hp	I_{2hd} A	P_{hd} kW	P_{hd} hp	
Three-phase supply voltage, 380...480 V							
-03A3-4	3.3	1.1	1.5	2.4	0.75	1	R1
-04A1-4	4.1	1.5	2	3.3	1.1	1.5	R1
-05A4-4	5.4	2.2	Note 1	4.1	1.5	Note 1	R1
-06A9-4	6.9	3	3	5.4	2.2	3	R1
-08A8-4	8.8	4	5	6.9	3	3	R1
-012A-4	11.9	5.5	7.5	8.8	4	5	R1
-015A-4	15.4	7.5	10	11.9	5.5	7.5	R2
-023A-4	23	11	15	15.4	7.5	10	R2
-031A-4	31	15	20	23	11	15	R3
-038A-4	38	18.5	25	31	15	20	R3
-045A-4	45	22	30	38	18.5	25	R3
-059A-4	59	30	40	44	22	30	R4
-072A-4	72	37	50	59	30	40	R4
-078A-4	77	Note 2	60	72	Note 2	50	R4
-087A-4	87	45	Note 1	72	37	Note 1	R4
-097A-4	97	Note 2	75	77	Note 2	60	R4
-125A-4	125	55	Note 1	87	45	Note 1	R5
-125A-4	125	Note 2	100	96	Note 2	75	R5
-157A-4	157	75	125	124	55	100	R6
-180A-4	180	90	150	156	75	125	R6
-195A-4	205	110	Note 1	162	90	Note 1	R6
-246A-4	246	132	200	192	110	150	R6
-290A-4	290	160	Note 1	246	132	200	R6

00467918.xls C

1. Not available in ACS550-U1 series.
2. Not available in ACS550-01 series.

Ratings, 500...600 V drives

Abbreviated column headers are described in section [Symbols](#) on page 279.

Type ACS550-U1- see below	Normal use			Heavy-duty use			Frame size
	I_{2N} A	P_N kW	P_N hp	I_{2hd} A	P_{hd} kW	P_{hd} hp	
Three-phase supply voltage, 500...600 V (Note 1)							
-02A7-6	2.7	1.5	2	2.4	1.1	1.5	R2
-03A9-6	3.9	2.2	3	2.7	1.5	2	R2
-06A1-6	6.1	4	5	3.9	2.2	3	R2
-09A0-6	9.0	5.5	7.5	6.1	4	5	R2
-011A-6	11	7.5	10	9.0	5.5	7.5	R2
-017A-6	17	11	15	11	7.5	10	R2
-022A-6	22	15	20	17	11	15	R3
-027A-6	27	18.5	25	22	15	20	R3
-032A-6	32	22	30	27	18.5	25	R4
-041A-6	41	30	40	32	22	30	R4
-052A-6	52	37	50	41	30	40	R4
-062A-6	62	45	60	52	37	50	R4
-077A-6	77	55	75	62	45	60	R6
-099A-6	99	75	100	77	55	75	R6
-125A-6	125	90	125	99	75	100	R6
-144A-6	144	110	150	125	90	125	R6

00467918.xls C

1. Not available in ACS550-01 series.

Symbols

Typical ratings:

Normal use (10% overload capability)

I_{2N} continuous rms current. 10% overload is allowed for one minute in ten minutes.

P_N typical motor power in normal use. The kilowatt power ratings apply to most IEC, 4-pole motors. The horsepower ratings apply to most 4-pole NEMA motors.

Heavy-duty use (50% overload capability)

I_{2hd} continuous rms current. 50% overload is allowed for one minute in ten minutes.

P_{hd} typical motor power in heavy duty use. The kilowatt power ratings apply to most IEC, 4-pole motors. The horsepower ratings apply to most 4-pole NEMA motors.

Sizing

The current ratings are the same regardless of the supply voltage within one voltage range. To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current. Also note that:

- the ratings apply for ambient temperature of 40 °C (104 °F)
- the maximum allowed motor shaft power is limited to $1.5 \cdot P_{hd}$. If the limit is exceeded, motor torque and current are automatically restricted. The function protects the input bridge of the drive against overload.

In multimotor systems, the output current of the drive must be equal to or greater than the calculated sum of the input currents of all motors.

Derating

The load capacity (current and power) decreases for certain situations, as defined below. In such situations, where full motor power is required, oversize the drive so that the derated value provides sufficient capacity.

For example, if your application requires 15.4 A of motor current and a 8 kHz switching frequency, calculate the appropriate drive size requirement as follows:

$$\text{The minimum size required} = 15.4 \text{ A} / 0.80 = 19.25 \text{ A}$$

Where: 0.80 is the derating for 8 kHz switching frequency (see section [Switching frequency derating](#) on page [280](#)).

Referring to I_{2N} in the ratings tables (starting from page [277](#)), the following drives exceed the I_{2N} requirement of 19.25 A: ACS550-x1-023A-4, or ACS550-x1-024A-2.

Temperature derating

In the temperature range +40 °C...50 °C (+104 °F...122 °F), the rated output current is decreased 1% for every 1 °C (1.8 °F) above +40 °C (+104 °F). Calculate the output current by multiplying the current given in the rating table by the derating factor.

Example If the ambient temperature is 50 °C (+122 °F), the derating factor is 100% - 1%/°C · 10 °C = 90% or 0.90.

The output current is then $0.90 \cdot I_{2N}$ or $0.90 \cdot I_{2hd}$.

Altitude derating

In altitudes 1000...4000 m (3300...13,200 ft) above sea level, the derating is 1% for every 100 m (330 ft). If the installation site is higher than 2000 m (6600 ft) above sea level, contact your local ABB representative for further information.

Single phase supply derating

For 208...240 V series drives, a single phase supply can be used. In that case, the derating is 50%.

Switching frequency derating

When using the 8 kHz switching frequency (parameter 2606),

- derate all rated currents and powers (including drive's overload currents) to 80%.

When using the 12 kHz switching frequency (parameter 2606),

- derate all rated currents and powers (including drive's overload currents) to 65% (to 50% for 600 V, R4 frame sizes, that is for ACS550-U1-032A-6 ... ACS550-U1-062A-6),
- derate ambient temperature maximum to 30 °C (86 °F).
- Note: The continuous maximum current is limited to I_{2hd} .

Note: Setting parameter 2607 SWITCH FREQ CTRL = 1 (ON) allows the drive to reduce the switching frequency if/when the drive's internal temperature exceeds 80 °C (with 12 kHz switching frequency) or 90 °C (with 8 kHz switching frequency). See the parameter description for 2607 for details.

Input power connections



WARNING! Do not operate the drive outside the nominal input line voltage range. Overvoltage can result in permanent damage to the drive.

Input power specifications

Input power (mains) connection specifications	
Voltage (U_1)	208/220/230/240 V AC 3-phase (or 1-phase) -15%...+10% for ACS550-x1-xxxx-2. 380/400/415/440/460/480 V AC 3-phase -15%...+10% for ACS550-x1-xxxx-4. 500/525/575/600 V AC 3-phase -15%...+10% for ACS550-U1-xxxx-6.
Prospective short-circuit current (IEC 629)	Maximum allowed prospective short-circuit current in the supply is 100 kA providing that the input power cable of the drive is protected with appropriate fuses. US: 100 000 AIC.
Frequency	48...63 Hz
Imbalance	Max. \pm 3% of nominal phase to phase input voltage
Fundamental power factor ($\cos \phi_1$)	0.98 (at nominal load)
Cable temperature rating	90 °C (194 °F) rating minimum

Disconnecting device for isolation

Install a hand-operated input disconnecting device (disconnecting means) between the AC power source and the drive. The disconnecting device must be of a type that can be locked to the open position for installation and maintenance work.

- **Europe:** To meet the European Union Directives, according to standard EN 60204-1, Safety of Machinery, the disconnecting device must be one of the following types:
 - a switch-disconnector of utilization category AC-23B (EN 60947-3)
 - a disconnector having an auxiliary contact that in all cases causes switching devices to break the load circuit before the opening of the main contacts of the disconnector (EN 60947-3)
 - a circuit breaker suitable for isolation in accordance with EN 60947-2.
- **Other regions:** The disconnecting device must conform to the applicable safety regulations.

Fuses

Branch circuit protection must be provided by the end user and sized per national and local electric codes. The following tables provide fuse recommendations for short circuit protection on the drive's input power.

The rated fuse currents given in the tables are the maximums for the mentioned fuse types. If smaller fuse ratings are used, check that the fuse rms current rating is larger than the input current.

Check that the operating time of the fuse is below 0.5 seconds. The operating time depends on the fuse type, the supply network impedance as well as the cross-sectional area, material and length of the supply cable. In case the 0.5 seconds operating time is exceeded with the gG or T fuses, ultra rapid (aR) fuses will in most cases reduce the operating time to an acceptable level.

Fuses, 208...240 V drives

ACS550-x1- see below	Input current A	Input power (mains) fuses		
		IEC 60269 gG (A)	UL Class T (A)	Bussmann type
-04A6-2	4.6	10	10	JJS-10
-06A6-2	6.6			
-07A5-2	7.5			
-012A-2	11.8	16	15	JJS-15
-017A-2	16.7	25	25	JJS-25
-024A-2	24.2		30	JJS-30
-031A-2	30.8	40	40	JJS-40
-046A-2	46.2	63	60	JJS-60
-059A-2	59.4		80	JJS-80
-075A-2	74.8	80	100	JJS-100
-088A-2	88.0	100	110	JJS-110
-114A-2	114	125	150	JJS-150
-143A-2	143	200	200	JJS-200
-178A-2	178	250	250	JJS-250
-221A-2	221	315	300	JJS-300
-248A-2	248		350	JJS-350

00467918.xls C

Fuses, 380...480 V drives

ACS550-x1- see below	Input current A	Input power (mains) fuses		
		IEC 60269 gG (A)	UL Class T (A)	Bussmann type
-03A3-4	3.3	10	10	JJS-10
-04A1-4	4.1			
-05A4-4	5.4			
-06A9-4	6.9			
-08A8-4	8.8		15	JJS-15
-012A-4	11.9	16		
-015A-4	15.4		20	JJS-20
-023A-4	23	25	30	JJS-30
-031A-4	31	35	40	JJS-40
-038A-4	38	50	50	JJS-50
-045A-4	45		60	JJS-60
-059A-4	59	63	80	JJS-80
-072A-4	72	80	90	JJS-90
-078A-4	77		100	JJS-100

ACS550-x1- see below	Input current A	Input power (mains) fuses		
		IEC 60269 gG (A)	UL Class T (A)	Bussmann type
-087A-4	87	125	125	JJS-125
-097A-4	97			
-125A-4	125	160	175	JJS-175
-157A-4	157	200	200	JJS-200
-180A-4	180	250	250	JJS-250
-195A-4	205			
-246A-4	246	315	350	JJS-350
-290A-4	290			

00467918.xls C

Fuses, 500...600 V drives

ACS550-U1- see below	Input current A	Input power (mains) fuses		
		IEC 60269 gG (A)	UL Class T (A)	Bussmann type
-02A7-6	2.7	10	10	JJS-10
-03A9-6	3.9			
-06A1-6	6.1			
-09A0-6	9.0	16	15	JJS-15
-011A-6	11			
-017A-6	17	25	25	JJS-25
-022A-6	22			
-027A-6	27	35	40	JJS-40
-032A-6	32			
-041A-6	41	50	50	JJS-50
-052A-6	52	60	60	JJS-60
-062A-6	62	80	80	JJS-80
-077A-6	77		100	JJS-100
-099A-6	99	125	150	JJS-150
-125A-6	125	160	175	JJS-175
-144A-6	144	200	200	JJS-200

00467918.xls C

Emergency stop devices

The overall design of the installation must include emergency stop devices and any other safety equipment that may be needed. Pressing STOP on the drive's control panel does NOT:

- generate an emergency stop of the motor
- separate the drive from dangerous potential.

Input power cables/wiring

Input wiring can be any of:

- a four conductor cable (three phases and ground/protective earth). Shielding is not required.
- four insulated conductors routed through conduit.

Size wiring according to local safety regulations, appropriate input voltage and the drive's load current.

Note: The conductor must be less than the maximum limit defined by the terminal size. Check the maximum wire size according to the table in section [Drive's power connection terminals](#) on page 286.

The table below lists copper and aluminium cable types for different load currents. These recommendations apply only for the conditions listed at the top of the table.

IEC				NEC	
Based on:				Based on:	
Max. load current A	Cu cable mm ²	Max. load current A	Al cable mm ²	Max. load current A	Cu wire size AWG/kcmil
14	3×1.5			22.8	14
20	3×2.5			27.3	12
27	3×4			36.4	10
34	3×6			50.1	8
47	3×10			68.3	6
62	3×16	61	3x25	86.5	4
79	3×25	75	3x35	100	3
98	3×35	91	3×50	118	2
119	3×50	117	3×70	137	1
153	3×70	143	3×95	155	1/0
186	3×95	165	3×120	178	2/0
215	3×120	191	3×150	205	3/0
249	3×150	218	3×185	237	4/0
284	3×185	257	3×240	264	250 MCM or 2 × 1
330	3×240	274	3× (3×50)	291	300 MCM or 2 × 1/0
		285	2× (3×95)	319	350 MCM or 2 × 2/0

Ground connections

For personnel safety, proper operation and reduction of electromagnetic emission/pick-up, the drive and the motor must be grounded at the installation site.

- Conductors must be adequately sized as required by safety regulations.
- Power cable shields must be connected to the drive PE terminal in order to meet safety regulations.
- Power cable shields are suitable for use as equipment grounding conductors only when the shield conductors are adequately sized as required by safety regulations.
- In multiple drive installations, do not connect drive terminals in series.

Corner-grounded TN systems




WARNING! Do not attempt to install or remove the EMC filter screws EM1, EM3, F1 or F2 while power is applied to the drive's input terminals.

Corner-grounded TN systems are defined in the following table. In such systems, disconnect the internal ground connection through the EMC filter capacitors (do this also if the grounding configuration of the system is unknown), see section *Disconnecting the internal EMC filter* on page 27.

Corner-grounded TN systems – EMC filter must be disconnected			
Grounded at the corner of the delta		Grounded at the mid point of a delta leg	
Single phase, grounded at an end point		Three phase "Variac" without solidly grounded neutral	

The EMC filter capacitors make an internal ground connection that reduces electro-magnetic emission. Where EMC (electro-magnetic compatibility) is a concern, and the system is symmetrically grounded, the EMC filter may be connected. For reference, the diagram on the right illustrates a symmetrically grounded TN system (TN-S system).



IT systems



WARNING! Do not attempt to install or remove the EMC filter screws EM1, EM3, F1 or F2 while power is applied to the drive's input terminals.

For IT systems (an ungrounded power system or a high-resistance-grounded [over 30 ohm] power system):

- Disconnect the ground connection to the internal EMC filter, see section [Disconnecting the internal EMC filter](#) on page [27](#).
- Where EMC requirements exist, check for excessive emission propagated to neighboring low voltage networks. In some cases, the natural suppression in transformers and cables is sufficient. If in doubt, use a supply transformer with static screening between the primary and secondary windings.
- Do NOT install an external RFI/EMC filter. Using an EMC filter grounds the input power through the filter capacitors, which could be dangerous and could damage the drive.

Drive's power connection terminals

The following table provides specifications for the drive's power connection terminals.

Note: See the recommended cable sizes for different load currents in section [Input power cables/wiring](#) on page [284](#).

Frame size	U1, V1, W1 U2, V2, W2 BRK \pm , UDC \pm terminals						Earthing PE terminal			
	Minimum wire size		Maximum wire size		Tightening torque		Maximum wire size		Tightening torque	
	mm ²	AWG	mm ²	AWG	N·m	lb·ft	mm ²	AWG	N·m	lb·ft
R1	0.75	18	10	8	1.4	1	10	8	1.4	1
R2	0.75	18	10	8	1.4	1	10	8	1.4	1
R3	2.5	14	25	3	2.5	1.8	16	6	1.8	1.3
R4	6	10	50	1/0	5.6	4	25	3	2	1.5
R5	6	10	70	2/0	15	11	70	2/0	15	11
R6	95 ¹	3/0 ¹	240	350 MCM	40	30	95	3/0	8	6

00467918.xls C

¹ See section [Power terminal considerations – R6 frame size](#) on page [287](#).

Power terminal considerations – R6 frame size




WARNING! For R6 power terminals, if screw-on terminal lugs are supplied, they can only be used for wire sizes that are 95 mm² (3/0 AWG) or larger. Smaller wires will loosen and may damage the drive. They require crimp-on ring lugs as described below.

Crimp-on ring lugs

On the R6 frame size, if screw-on terminal lugs are supplied but the cable size used is less than 95 mm² (3/0 AWG), or if no screw-on terminal lugs are supplied at all, use crimp-on ring lugs according to the following procedure.

1. Select appropriate ring lugs from the following table.
2. Remove the screw-on terminal lugs, if supplied.
3. Attach the ring lugs to the drive end of the cables.
4. Isolate the ends of the ring lugs with insulating tape or shrink tubing.
5. Attach the ring lugs to the drive.



X60002


Wire size		Manufacturer	Ring lug	Crimping tool	No. of crimps
mm ²	kcmil/AWG				
16	6	Burndy	YAV6C-L2	MY29-3	1
		Ilasco	CCL-6-38	ILC-10	2
25	4	Burndy	YA4C-L4BOX	MY29-3	1
		Ilasco	CCL-4-38	MT-25	1
35	2	Burndy	YA2C-L4BOX	MY29-3	2
		Ilasco	CRC-2	IDT-12	1
		Ilasco	CCL-2-38	MT-25	1
50	1	Burndy	YA1C-L4BOX	MY29-3	2
		Ilasco	CRA-1-38	IDT-12	1
		Ilasco	CCL-1-38	MT-25	1
		Thomas & Betts	54148	TBM-8	3
55	1/0	Burndy	YA25-L4BOX	MY29-3	2
		Ilasco	CRB-0	IDT-12	1
		Ilasco	CCL-1/0-38	MT-25	1
		Thomas & Betts	54109	TBM-8	3

Wire size		Manufacturer	Ring lug	Crimping tool	No. of crimps
mm ²	kcmil/AWG				
70	2/0	Burndy	YAL26T38	MY29-3	2
		IlSCO	CRA-2/0	IDT-12	1
		IlSCO	CCL-2/0-38	MT-25	1
		Thomas & Betts	54110	TBM-8	3
95	3/0	Burndy	YAL27T38	MY29-3	2
		IlSCO	CRA-3/0	IDT-12	1
		IlSCO	CCL-3/0-38	MT-25	1
		Thomas & Betts	54111	TBM-8	3
95	3/0	Burndy	YA28R4	MY29-3	2
		IlSCO	CRA-4/0	IDT-12	1
		IlSCO	CCL-4/0-38	MT-25	2
		Thomas & Betts	54112	TBM-8	4

Screw-on terminal lugs

Use the following procedure to attach cables if screw-on terminal lugs are supplied and the cable size is 95 mm² (3/0 AWG) or larger.

1. Attach the supplied screw-on lugs to the drive end of the cables.
2. Attach screw-on lugs to the drive.



Motor connections



WARNING! Never connect line power to the drive output terminals: U₂, V₂ or W₂. Line voltage applied to the output can result in permanent damage to the drive. If frequent bypassing is required, use mechanically interlocked switches or contactors.



WARNING! Do not connect any motor with a nominal voltage less than one half of the drive's nominal input voltage.



WARNING! Disconnect the drive before conducting any voltage tolerance (Hi-Pot) test or insulation resistance (Megger) test on the motor or motor cables. Do not conduct these tests on the drive.

Motor connection specifications

Motor connection specifications		
Voltage (U₂)	0...U ₁ , 3-phase symmetrical, U _{max} at the field weakening point	
Frequency	0...500 Hz	
Frequency resolution	0.01 Hz	
Current	See section Ratings on page 277 .	
Field weakening point	10...500 Hz	
Switching frequency	Selectable. See the availability in the table below.	
		1, 2, 4 and 8 kHz
208...240 V	All types	Frame sizes R1...R4 in scalar control mode
380...480 V	All types	Frame sizes R1...R4 (except ACS550-01-097A-4) in scalar control mode
500...600 V	All types	Frame sizes R2...R4 in scalar control mode
Cable temperature rating	90 °C (194 °F) rating minimum.	
Maximum motor cable length	See section Motor cable lengths on page 289 .	

Motor cable lengths

Maximum motor cable lengths for 400 V and 600 V drives are given in the sections below.

In multimotor systems, the calculated sum of all motor cable lengths must not exceed the maximum motor cable length given in the appropriate table below.

Motor cable length for 400 V drives

The table below shows the maximum motor cable lengths for 400 V drives with different switching frequencies. Examples for using the table are also given.

Frame size	Maximum cable length for 400 V drives																	
	EMC limits												Operational limits					
	Second environment (category C3 ¹)						First environment (category C2 ¹)						Basic unit				With du/dt filters	
	1 kHz			4 kHz			8 kHz			1 kHz			4 kHz			8 kHz		
	m	ft	m	ft	m	ft	m	ft	m	ft	m	ft	m	ft	m	ft	m	ft
R1	300	980	300	980	300	980	300	980	300	980	300	980	100	330	100	330	150	490
R2	300	980	300	980	300	980	300	980	100	330	30	98	200	660	100	330	250	820
R3	300	980	300	980	300	980	300	980	75	245	75	245	200	660	100	330	250	820
R4	300	980	300	980	300	980	300	980	75	245	75	245	200	660	100	330	300	980
R5	100	330	100	330	100	330	100	330	100	330	100	330	300	980	150 ²	490 ²	300	980
R6	100	330	100	330	3	3	100	330	100	330	3	3	300	980	150 ²	490 ²	300	980

¹ See the new terms in section [IEC/EN 61800-3:2004 Definitions](#) on page 311.

² 12 kHz switching frequency is not available.

³ Not tested.

Sine filters further extend the cable lengths.

Under heading "Operational limits", the "Basic unit" columns define the cable lengths with which the basic drive unit works without problems within the drive specification, without installing any further options. Column "With du/dt filters" defines the cable lengths when an external du/dt filter is used.

The columns under heading "EMC limits" show the maximum cable lengths with which the units have been tested for EMC emissions. The factory guarantees that these cable lengths meet the EMC standard requirements.

If external sine filters are installed, longer cable lengths can be used. With sine filters the limiting factors are the voltage drop of the cable, which has to be taken into account in engineering, as well as the EMC limits (where applicable).

The default switching frequency is 4 kHz.



WARNING! Using a motor cable longer than specified in the table above may cause permanent damage to the drive.

Examples for using the table:

Requirements	Checking and conclusions
R1 frame size, 8 kHz fsw, Category C2, 150 m (490 ft) cable	<p>Check operational limits for R1 and 8 kHz -> for a 150 m (490 ft) cable a du/dt filter is needed.</p> <p>Check EMC limits -> EMC requirements for Category C2 are met with a 150 m (490 ft) cable.</p>

Requirements	Checking and conclusions
R3 frame size, 4 kHz fsw, Category C3, 300 m (980 ft) cable	<p>Check operational limits for R3 and 4 kHz -> a 300 m (980 ft) cable cannot be used even with a du/dt filter. A sine filter must be used and the voltage drop of the cable must be taken into account in the installation.</p> <p>Check EMC limits -> EMC requirements for Category C3 are met with a 300 m (980 ft) cable.</p>
R5 frame size, 8 kHz fsw, Category C3, 150 m (490 ft) cable	<p>Check operational limits for R5 and 8 kHz -> for a 150 m (490 ft) cable the basic unit is sufficient.</p> <p>Check EMC limits -> EMC requirements for Category C3 cannot be met with a 300 m (980 ft) cable. The installation configuration is not possible. An EMC plan is recommended to overcome the situation.</p>
R6 frame size, 4 kHz fsw, EMC limits not applicable, 150 m (490 ft) cable	<p>Check operational limits for R6 and 4 kHz -> for a 150 m (490 ft) cable the basic unit is sufficient.</p> <p>EMC limits do not need to be checked as there are no EMC requirements.</p>

Motor cable length for 600 V drives

The table below shows the maximum motor cable lengths for 600 V drives with different switching frequencies. As the 600 V drives are not CE approved, cable lengths for EMC limits are not given.

Maximum cable length for 600 V drives				
Frame size	Operational limits			
	1/4 kHz		8/12 kHz	
	m	ft	m	ft
R2	100	330	100	330
R3...R4	200	660	100	330
R6	300	980	150 ²	490 ²

² 12 kHz switching frequency is not available.



WARNING! Using a motor cable longer than specified in the table above may cause permanent damage to the drive.

Motor thermal protection

According to regulations, the motor must be protected against thermal overload and the current must be switched off when overload is detected. The drive includes a motor thermal protection function that protects the motor and switches off the current when necessary. Depending on a drive parameter value (see parameter 3501 SENSOR TYPE), the function either monitors a calculated temperature value (based on a motor thermal model, see parameters 3005 MOT THERM PROT ... 3009 BREAK POINT FREQ) or an actual temperature indication given by motor temperature sensors (see [Group 35: MOTOR TEMP MEAS](#)). The user can tune the thermal model further by feeding in additional motor and load data.

The most common temperature sensors are:

- motor sizes IEC180...225: thermal switch (e.g. Klixon)
- motor sizes IEC200...250 and larger: PTC or PT100.

Ground fault protection

ACS550 internal fault logic detects ground faults in the drive, motor, or motor cable. This fault logic:

- is NOT a personal safety or fire protection feature
- can be disabled using parameter 3017 EARTH FAULT
Note: Disabling earth fault (ground fault) may void the warranty.
- could be tripped by leakage currents (input power to ground) associated with long high capacitance motor cables.

Grounding and routing

Motor cable shielding

Motor cables require shielding using conduit, armored cable or shielded cable.

- Conduit – When using conduit:
 - Bridge joints with a ground conductor bonded to the conduit on each side of the joint.
 - Bond conduit run to the drive enclosure.
 - Use a separate conduit run for motor cables (also separate input power and control cables).
 - Use a separate conduit run for each drive.
- Armored cable – When using armored cable:
 - Use six-conductor (3 phases and 3 grounds), type MC continuous corrugated aluminium armor cable with symmetrical grounds.
 - Armored motor cable can share a cable tray with input power cables, but not with control cables.
- Shielded cable – For shielded cable details, see section [Motor cable requirements for CE & C-Tick compliance](#) on page [293](#).

Grounding

See section [Ground connections](#) on page [285](#).

For CE compliant installations and installations where EMC emissions must be minimized, see section [Effective motor cable shields](#) on page [294](#).

Drive's motor connection terminals


The drive's motor and input power terminals have the same specifications. See section [Drive's power connection terminals](#) on page [286](#).

Motor cable requirements for CE & C-Tick compliance

The requirements in this section apply for CE or C-Tick compliance.

Minimum requirement (CE & C-Tick)

The motor cable must be a symmetrical three conductor cable with a concentric PE conductor or a four conductor cable with a concentric shield, however, a symmetrical constructed PE conductor is always recommended. The following figure shows the minimum requirement for the motor cable shield (for example, MCMK, Draka NK Cables).




Recommendation for conductor layout

The following figure compares conductor layout features in motor cables.

<p>Recommended (CE & C-Tick)</p> <p>Symmetrical shielded cable: three phase conductors and a concentric or otherwise symmetrically constructed PE conductor, and a shield</p>	<p>Allowed (CE & C-Tick)</p> <p>A separate PE conductor is required if the conductivity of the cable shield is < 50% of the conductivity of the phase conductor.</p>
<p>Not allowed for motor cables (CE & C-Tick)</p> <p>A four-conductor system: three phase conductors and a protective conductor, without a shield.</p>	<p>Allowed for motor cables with phase conductor cross section up to 10 mm².</p>

Effective motor cable shields

The general rule for cable shield effectiveness is: the better and tighter the cable's shield, the lower the radiated emission level. The following figure shows an example of an effective construction (for example Ölflex-Servo-FD 780 CP, Lappkabel or MCCMK, NK Cables).



EN 61800-3 compliant motor cables

The most efficient EMC filtering can be achieved by following these rules:

- Motor cables must have an effective shield as described in section [Effective motor cable shields](#) on page [294](#).
- Motor cable shield wires must be twisted together into a bundle (pig-tail) – the bundle length must be less than five times its width – and connected to the terminal marked \perp (at the bottom right-hand corner of the drive).
- At the motor end, the motor cable shield must be earthed 360 degrees with an EMC cable gland, or the shield wires must be twisted together into a bundle (pig-tail) not longer than five times its width and connected to the PE terminal of the motor.
- See section [Motor cable length for 400 V drives](#), columns “[EMC limits](#)” on page [290](#) to check the maximum motor cable lengths and the need for filters for 400 V drives for IEC/EN 61800-3 compliance.



WARNING! Do not use RFI/EMC filters on IT systems.

Brake components

Availability


Braking availability for ACS550 drives, by frame size is:

- R1 and R2 – a built-in brake chopper is standard equipment. Add appropriate resistor, as determined using the following section. Resistors are available from ABB.
- R3...R6 – does not include an internal brake chopper. Connect a chopper and a resistor, or a brake unit to the DC link terminals on the drive. Contact your ABB representative for appropriate parts.


Selecting the braking resistors (frame sizes R1 and R2)

Braking resistor must meet three requirements:

- Resistance must be always higher than the minimum value R_{MIN} defined for the drive type in the following tables. Never use resistance below this value.
- Resistance must be low enough to be able to produce the desired braking torque. To achieve the maximum braking torque (the larger of 150% of heavy duty or 110% of nominal duty), the resistance must not exceed R_{MAX} . If maximum braking torque is not necessary, resistor values can exceed R_{MAX} .
- The resistor power rating must be high enough to dissipate the braking power. This requirement involves many factors:
 - the maximum continuous power rating for the resistor(s)
 - the rate at which the resistor changes temperature (resistor thermal time constant)
 - maximum braking time ON – If the regeneration (braking) power is larger than the resistor rated power, there is a limit to the ON time, or the resistor overheats before the OFF period begins.
 - minimum braking time OFF – If the regeneration (braking) power is larger than the resistor rated power, the OFF time must be large enough for the resistor to cool between ON periods.



- the peak braking power requirement
- type of braking (deceleration to zero vs. overhauling load) – During deceleration to zero, the generated power steadily decreases, averaging half of the peak power. For an overhauling load, the braking is countering an external force (gravity for example) and the braking power is constant. The total heat generated from an overhauling load is double the heat generated from deceleration to zero speed (for the same peak torque and ON time).



The many variables in the last requirement above are most easily dealt with using the following tables.

- First, determine your maximum braking time ON (ON_{MAX}), minimum braking time OFF (OFF_{MIN}) and load type (deceleration or overhauling load).
- Calculate duty cycle:

$$\text{Duty cycle} = \frac{ON_{MAX}}{(ON_{MAX} + OFF_{MIN})} \cdot 100\%$$

- In the appropriate table, find the column that best matches your data:
 - $ON_{MAX} \leq$ column specification and
 - Duty cycle \leq column specification
- Find the row that matches your drive.
- The minimum power rating for deceleration to zero is the value in the selected row/column.
- For overhauling loads, double the rating in the selected row/column, or use the "Continuous ON" column.

208...240 V drives

Type ACS550- 01/U1- see below	Resistance		Resistor ¹ minimum continuous power rating					
	R_{MAX}	R_{MIN}	Deceleration-to-zero rating				P_{rcont} Continuous ON > 60 s ON $> 25\%$ Duty	
			P_{r3} ≤ 3 s ON ≥ 27 s OFF $\leq 10\%$ Duty	P_{r10} ≤ 10 s ON ≥ 50 s OFF $\leq 17\%$ Duty	P_{r30} ≤ 30 s ON ≥ 180 s OFF $\leq 14\%$ Duty	P_{r60} ≤ 60 s ON ≥ 180 s OFF $\leq 25\%$ Duty		
	ohm	ohm	W	W	W	W	W	W
Three-phase supply voltage, 208...240 V								
-04A6-2	234	80	45	80	120	200	1100	
-06A6-2	160	80	65	120	175	280	1500	
-07A5-2	117	44	85	160	235	390	2200	
-012A-2	80	44	125	235	345	570	3000	
-017A-2	48	44	210	390	575	950	4000	
-024A-2	32	30	315	590	860	1425	5500	
-031A-2	23	22	430	800	1175	1940	7500	

¹ Resistor time constant specification must be ≥ 85 seconds.

380...480 V drives

Type ACS550- 01/U1- see below	Resistance		Resistor ¹ minimum continuous power rating							
	R_{MAX}	R_{MIN}	Deceleration-to-zero rating							
			P_{r3}	P_{r10}	P_{r30}	P_{r60}	P_{rcont} Continuous ON > 60 s ON > 25% Duty			
			≤ 3 s ON ≥ 27 s OFF $\leq 10\%$ Duty	≤ 10 s ON ≥ 50 s OFF $\leq 17\%$ Duty	≤ 30 s ON ≥ 180 s OFF $\leq 14\%$ Duty	≤ 60 s ON ≥ 180 s OFF $\leq 25\%$ Duty				
			ohm	ohm	W	W	W	W		
Three-phase supply voltage, 380...480 V										
-03A3-4	641	120	65	120	175	285	1100			
-04A1-4	470	120	90	160	235	390	1500			
-05A4-4	320	120	125	235	345	570	2200			
-06A9-4	235	80	170	320	470	775	3000			
-08A8-4	192	80	210	400	575	950	4000			
-012A-4	128	80	315	590	860	1425	5500			
-015A-4	94	63	425	800	1175	1950	7500			
-023A-4	64	63	625	1175	1725	2850	11000			

¹ Resistor time constant specification must be ≥ 85 seconds.

500...600 V drives

Type ACS550- U1- see below	Resistance		Resistor ¹ minimum continuous power rating							
	R_{MAX}	R_{MIN}	Deceleration-to-zero rating							
			P_{r3}	P_{r10}	P_{r30}	P_{r60}	P_{rcont} Continuous ON > 60 s ON > 25% Duty			
			≤ 3 s ON ≥ 27 s OFF $\leq 10\%$ Duty	≤ 10 s ON ≥ 50 s OFF $\leq 17\%$ Duty	≤ 30 s ON ≥ 180 s OFF $\leq 14\%$ Duty	≤ 60 s ON ≥ 180 s OFF $\leq 25\%$ Duty				
			ohm	ohm	W	W	W	W		
Three-phase supply voltage, 500...600 V										
-02A7-6	548	80	93	175	257	425	1462			
-03A9-6	373	80	137	257	377	624	2144			
-06A1-6	224	80	228	429	629	1040	3573			
-09A0-6	149	80	342	643	943	1560	5359			
-011A-6	110	60	467	877	1286	2127	7308			
-017A-6	75	60	685	1286	1886	3119	10718			

¹ Resistor time constant specification must be ≥ 85 seconds.



WARNING! Never use a brake resistor with a resistance below the minimum value specified for the particular drive. The drive and the internal chopper are not able to handle the overcurrent caused by the low resistance.

Symbols

R_{MIN} – Minimum allowed resistance of the braking resistor.

R_{MAX} – Maximum resistance allowed if maximum braking torque is necessary.

P_{rx} – Duty-cycle based resistor power rating in deceleration braking, where “x” is ON_{MAX} time.

Installing and wiring resistors

All resistors must be installed outside the drive module in a place where they can dissipate heat.



WARNING! The surface temperature of the resistor is very high, and air flowing from the resistor is very hot. Materials near the brake resistor must be non-flammable. Provide protection from accidental contact with the resistor.

To ensure that the input fuses protect the resistor cable, use resistor cables with the same rating as used for the power input to the drive.


The maximum length of the resistor cable(s) is 10 m (33 ft). See section [Power connection diagrams](#) on page [25](#) for the resistor cable connection points.

Mandatory circuit protection

The following setup is essential for safety – it interrupts the main supply in fault situations involving chopper shorts:

- Equip the drive with a main contactor.
- Wire the contactor so that it opens if the resistor thermal switch opens (an overheated resistor opens the contactor).

Below is a simple wiring diagram example.



Parameter set-up

To enable dynamic braking, switch off the drive's overvoltage control [Set parameter 2005 = 0 (DISABLE)].

Control connections


Control connection specifications

Control connection specifications	
Analog inputs and outputs	See section Control terminals table on page 28.
Digital inputs	Digital input impedance 1.5 kohm. Maximum voltage for digital inputs is 30 V.
Relays (digital outputs)	<ul style="list-style-type: none"> Max. contact voltage: 30 V DC, 250 V AC Max. contact current / power: 6 A, 30 V DC; 1500 VA, 250 V AC Max. continuous current: 2 A rms ($\cos \varphi = 1$), 1 A rms ($\cos \varphi = 0.4$) Minimum load: 500 mW (12 V, 10 mA) Contact material: Silver-nickel (AgN) Isolation between relay digital outputs, test voltage: 2.5 kV rms, 1 minute
Cable specifications	See section Control terminals table on page 28.


Control cables

General recommendations

Use multi-core cables with a braided copper wire shield, temperature rated at 60 °C (140 °F) or above:



Double shielded
Example: JAMAK by Draka NK Cables



Single shielded
Example: NOMAK by Draka NK Cables

For digital and analog I/O cables, twist the shield together into a bundle (pig-tail) not longer than five times its width and connect it to terminal X1-1 at the drive end. Leave the other end of the cable shield unconnected.

For connecting the shield wires of the RS485 cable, see the instructions (and notes) in section [Mechanical and electrical installation – EFB](#) on page 204.

Route control cables to minimize radiation to the cable:

- Route as far away as possible from the input power and motor cables (at least 20 cm [8 in]).
- Where control cables must cross power cables, make sure they are at an angle as near 90° as possible.
- Stay at least 20 cm (8 in) from the sides of the drive.

Use care in mixing signal types on the same cable:

- Do not mix relay-controlled signals using more than 30 V and other control signals in the same cable.
- Run relay-controlled signals as twisted pairs (especially if voltage > 48 V). Relay-controlled signals using less than 48 V can be run in the same cables as digital input signals.

Note: Never mix 24 V DC and 115/230 V AC signals in the same cable.

Analog cables

Recommendations for analog signal runs:

- Use double shielded, twisted pair cable.
- Use one individually shielded pair for each signal.
- Do not use a common return for different analog signals.

Digital cables

Recommendation for digital signal runs: A double shielded cable is the best alternative, but single-shielded, twisted, multi-pair cable is also usable.

Control panel cable

If the control panel is connected to the drive with a cable, use only Category 5 Patch ethernet cable. The maximum length that is tested to meet EMC specifications is 3 m (9.8 ft). Longer cables are susceptible to electromagnetic noise and must be user-tested to verify that EMC requirements are met. Where long runs are required (especially for runs longer than about 12 m [40 ft]), use a RS232/RS485 converter at each end and run RS485 cable.

Drive's control connection terminals

The following table provides specifications for the drive's control terminals

Frame size	Control			
	Maximum wire size ¹		Tightening torque	
	mm ²	AWG	N·m	lb·ft
All	1.5	16	0.4	0.3

¹ Values given for solid wires.
For stranded wires, the maximum size is 1 mm².

Efficiency

Approximately 98% at nominal power level.

Losses, cooling data and noise

Cooling specifications	
Method	Internal fan, flow direction from bottom to top.
Requirement	Free space above and below the ACS550 drive: 200 mm (8 in). Free space is not required on the drive's sides – ACS550 drives can be mounted side-by-side.

Air flow, 208...240 V drives

The following table lists the requirements for the cooling air flow data for 208...240 V drives at full load in all ambient conditions listed in [Ambient conditions](#) on page 307.

Drive	Heat dissipation	Air flow		Noise		
ACS550-x1-	Frame size	W	BTU/hr	m ³ /h	ft ³ /min	dB
-04A6-2	R1	55	189	44	26	52
-06A6-2	R1	73	249	44	26	52
-07A5-2	R1	81	276	44	26	52
-012A-2	R1	118	404	44	26	52
-017A-2	R1	161	551	44	26	52
-024A-2	R2	227	776	88	52	66
-031A-2	R2	285	973	88	52	66
-046A-2	R3	420	1434	134	79	67
-059A-2	R3	536	1829	134	79	67
-075A-2	R4	671	2290	280	165	75
-088A-2	R4	786	2685	280	165	75
-114A-2	R4	1014	3463	280	165	75
-143A-2	R6	1268	4431	405	238	77
-178A-2	R6	1575	5379	405	238	77
-221A-2	R6	1952	6666	405	238	77
-248A-2	R6	2189	7474	405	238	77

00467918.xls C

Air flow, 380...480 V drives

The following table lists the requirements for the cooling air flow data for 380...480 V drives at full load in all ambient conditions listed in [Ambient conditions](#) on page 307.

Drive	Heat dissipation	Air flow		Noise		
ACS550-x1-	Frame size	W	BTU/hr	m ³ /h	ft ³ /min	dB
-03A3-4	R1	40	137	44	26	52
-04A1-4	R1	52	178	44	26	52
-05A4-4	R1	73	249	44	26	52
-06A9-4	R1	97	331	44	26	52
-08A8-4	R1	127	434	44	26	52
-012A-4	R1	172	587	44	26	52

Drive		Heat dissipation		Air flow		Noise
ACS550-x1-	Frame size	W	BTU/hr	m ³ /h	ft ³ /min	dB
-015A-4	R2	232	792	88	52	66
-023A-4	R2	337	1151	88	52	66
-031A-4	R3	457	1561	134	79	67
-038A-4	R3	562	1919	134	79	67
-045A-4	R3	667	2278	134	79	67
-059A-4	R4	907	3098	280	165	75
-072A-4	R4	1120	3825	280	165	75
-078A-4	R4	1295	4423	250	147	75
-087A-4	R4	1440	4918	280	165	75
-097A-4	R4	1440	4918	280	165	75
-125A-4	R5	1940	6625	350	205	75
-157A-4	R6	2310	7889	405	238	77
-180A-4	R6	2810	9597	405	238	77
-195A-4	R6	3050	10416	405	238	77
-246A-4	R6	3260	11134	405	238	77
-290A-4	R6	3850	13125	405	238	77

00467918.xls C

Air flow, 500...600 V drives

The following table lists the requirements for the cooling air flow data for 500...600 V drives at full load in all ambient conditions listed in [Ambient conditions](#) on page [307](#).

Drive		Heat dissipation		Air flow		Noise
ACS550-U1-	Frame size	W	BTU/hr	m ³ /h	ft ³ /min	dB
-02A7-6	R2	52	178	88	52	66
-03A9-6	R2	73	249	88	52	66
-06A1-6	R2	127	434	88	52	66
-09A0-6	R2	172	587	88	52	66
-011A-6	R2	232	792	88	52	66
-017A-6	R2	337	1151	88	52	66
-022A-6	R3	457	1561	134	79	67
-027A-6	R3	562	1919	134	79	67
-032A-6	R4	667	2278	280	165	75
-041A-6	R4	907	3098	280	165	75
-052A-6	R4	1117	3815	280	165	75
-062A-6	R4	1357	4634	280	165	75
-077A-6	R6	2310	7889	405	238	77
-099A-6	R6	2310	7889	405	238	77
-125A-6	R6	2310	7889	405	238	77


Drive		Heat dissipation		Air flow		Noise
ACS550-U1-	Frame size	W	BTU/hr	m ³ /h	ft ³ /min	dB
-144A-6	R6	2310	7889	405	238	77

00467918.xls C

Dimensions and weights

The dimensions and mass for the ACS550 depend on the frame size and enclosure type. If unsure of the frame size, first, find the "Type" designation on the drive labels (see sections *The labels contain information on the Type designation (page 17)*, *Ratings and frame size (page 17)*, *Serial number (page 17)*, *degree of protection (see also Degrees of protection on page 306) and valid markings (see also Markings on page 309)*, on page 17 and *Drive labels* on page 16). Then look up that type designation in the rating tables (see chapter *Technical data*, page 277), to determine the frame size.

Mounting dimensions



X0032


Ref.	IP21 / UL type 1 and IP54 / UL type 12 – Dimensions for each frame size											
	R1		R2		R3		R4		R5		R6	
	mm	in	mm	in	mm	in	mm	in	mm	in	mm	in
W1 ¹	98.0	3.9	98.0	3.9	160	6.3	160	6.3	238	9.4	263	10.4
W2 ¹	--	--	--	--	98.0	3.9	98.0	3.9	--	--	--	--
H1 ¹	318	12.5	418	16.4	473	18.6	578	22.8	588	23.2	675	26.6
a	5.5	0.2	5.5	0.2	6.5	0.25	6.5	0.25	6.5	0.25	9.0	0.35
b	10.0	0.4	10.0	0.4	13.0	0.5	13.0	0.5	14.0	0.55	18.0	0.71
c	5.5	0.2	5.5	0.2	8.0	0.3	8.0	0.3	8.5	0.3	8.5	0.3
d	5.5	0.2	5.5	0.2	6.5	0.25	6.5	0.25	6.5	0.25	9.0	0.35

¹ Center to center dimension.

Outside dimensions

Drives with IP21 / UL type 1 enclosures

Types ACS550-x1-221A-2,
ACS550-x1-246A-4, ACS550-x1-248A-2,
and ACS550-01-290A-4, frame size R6




Ref.	R1		R2		R3		R4		R5		R6	
	mm	in	mm	in								
W	125	4.9	125	4.9	203	8.0	203	8.0	265	10.4	302	11.9
H	330	13.0	430	16.9	490	19.3	596	23.5	602	23.7	700	27.6
H2	315	12.4	415	16.3	478	18.8	583	23.0	578	22.8	698	27.5
H3	369	14.5	469	18.5	583	23.0	689	27.1	736	29.0	888 ¹	35.0 ¹
D	212	8.3	222	8.7	231	9.1	262	10.3	286	11.3	400	15.8

00467918.xls C

1. ACS550-x1-221A-2, ACS550-x1-246A-4, ACS550-x1-248A-2 and ACS550-x1-290A-4: 981 mm / 38.6 in.

Drives with IP54 / UL type 12 enclosures

Type ACS550-01-290A-4, IP54
(UL type 12 not available), frame size R6



IP54 / UL type 12 – Dimensions for each frame size												
Ref.	R1		R2		R3		R4		R5		R6 ²	
	mm	in	mm	in								
W	213	8.4	213	8.4	257	10.1	257	10.1	369	14.5	410	16.1
W2	222	8.8	222	8.8	267	10.5	267	10.5	369	14.5	410	16.1
H3	461	18.2	561	22.1	629	24.8	760	29.9	775	30.5	924 ¹	36.4 ¹
D	234	9.2	245	9.7	254	10.0	284	11.2	309	12.2	423	16.7

00467918.xls C

1. ACS550-01-290A-4: 1119 mm / 44.1 in.
2. UL type 12 not available for ACS550-01-290A-4.

Weight

The following table lists typical maximum weights for each frame size. Variations within each frame size (due to components associated with voltage/current ratings and options) are minor.

Enclosure	Weight											
	R1		R2		R3		R4		R5		R6	
	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb
IP21 / UL type 1	6.5	14.3	9.0	19.8	16	35	24	53	34	75	69 ¹	152 ¹
IP54 / UL type 12	8.0	17.6	11.0	24.3	17.0	37.5	26.0	57.3	42.0	93.0	86.0 ²	190 ²

00467918.xls C

1. ACS550-x1-221A-2, IP21 / UL type 1: 70 kg / 154 lb
ACS550-x1-246A-4, IP21 / UL type 1: 70 kg / 154 lb,
ACS550-x1-248A-2, IP21 / UL type 1: 80 kg / 176 lb.
ACS550-01-290A-4, IP21 / UL type 1: 80 kg / 176 lb.
2. ACS550-x1-246A-4, IP54 / UL type 12: 80 kg / 176 lb
ACS550-01-290A-4, IP54: 90 kg / 198 lb (UL type 12 not available).

Degrees of protection

Available enclosures:

- IP21 / UL type 1 enclosure. The site must be free of airborne dust, corrosive gases or liquids, and conductive contaminants such as condensation, carbon dust and metallic particles.
- IP54 / UL type 12 enclosure. This enclosure provides protection from airborne dust and light sprays or splashing water from all directions.

Note: UL type 12 enclosure is not available for type ACS550-01-290A-4.

Compared to the IP21 / UL type 1 enclosure, the IP54 / UL type 12 enclosure has:

- the same internal plastic shell as the IP21 enclosure
- a different outer plastic cover
- an additional internal fan to improve cooling
- larger dimensions
- the same rating (does not require a derating).

Ambient conditions

The following table lists the ACS550 environmental requirements.

Ambient environment requirements		
	Installation site	Storage and transportation in the protective package
Altitude	<ul style="list-style-type: none"> • 0...1000 m (0...3 300 ft) • 1000...2000 m (3 300...6 600 ft) if P_N and I_{2N} derated 1% every 100 m above 1000 m (300 ft above 3 300 ft) 	
Ambient temperature	<ul style="list-style-type: none"> • Min. -15 °C (5 °F) – no frost allowed • Max. (fsw = 1 or 4) 40 °C (104 °F); 50 °C (122 °F) if P_N and I_{2N} derated to 90% • Max. (fsw = 8) 40 °C (104 °F) if P_N and I_{2N} derated to 80% • Max. (fsw = 12) 30 °C (86 °F) if P_N and I_{2N} derated to 65% (to 50% for 600 V, R4 frame sizes, that is for ACS550-U1-032A-6 ... ACS550-U1-062A-6) 	-40...70 °C (-40...158 °F)
Relative humidity	5...95%, no condensation allowed	
Contamination levels (IEC 60721-3-3)	<ul style="list-style-type: none"> • No conductive dust allowed. • The ACS550 should be installed in clean air according to enclosure classification. • Cooling air must be clean, free from corrosive materials and free from electrically conductive dust. • Chemical gases: Class 3C2 • Solid particles: Class 3S2 	<p>Storage</p> <ul style="list-style-type: none"> • No conductive dust allowed. • Chemical gases: Class 1C2 • Solid particles: Class 1S2 <p>Transportation</p> <ul style="list-style-type: none"> • No conductive dust allowed. • Chemical gases: Class 2C2 • Solid particles: Class 2S2

The following table lists the standard stress testing that the ACS550 passes.

Stress tests		
	Without shipping package	Inside shipping package
Sinusoidal vibration	Mechanical conditions: In accordance with IEC 60721-3-3, Class 3M4 <ul style="list-style-type: none"> • 2...9 Hz 3.0 mm (0.12 in) • 9...200 Hz 10 m/s² (33 ft/s²) 	In accordance with ISTA 1A and 1B specifications.
Shock	Not allowed	In accordance with IEC 68-2-29: max. 100 m/s ² (330 ft/s ²), 11ms
Free fall	Not allowed	<ul style="list-style-type: none"> • 76 cm (30 in), frame size R1 • 61cm (24 in), frame size R2 • 46 cm (18 in), frame size R3 • 31 cm (12 in), frame size R4 • 25 cm (10 in), frame size R5 • 15 cm (6 in), frame size R6

Materials

Material specifications	
Drive enclosure	<ul style="list-style-type: none"> • PC/ABS 2.5 mm, color NCS 1502-Y or NCS 7000-N • Hot-dip zinc coated steel sheet 1.5...2 mm, thickness of coating 20 micrometers. If the surface is painted, the total thickness of the coating (zinc and paint) is 80...100 micrometers. • Cast aluminium AISI • Extruded aluminium AISI
Package	Corrugated board, expanded polystyrene, plywood, raw wood (heat dried). Package wrap consists of one or more of the following: PE-LD plastic wrap, PP or steel bands.
Disposal	<p>The drive contains raw materials that should be recycled to preserve energy and natural resources. The package materials are environmentally compatible and recyclable. All metal parts can be recycled. The plastic parts can either be recycled or burned under controlled circumstances, according to local regulations. Most recyclable parts are marked with recycling marks.</p> <p>If recycling is not feasible, all parts excluding electrolytic capacitors and printed circuit boards can be landfilled. The DC capacitors contain electrolyte and, if the drive is not provided with the RoHS marking, the printed circuit boards contain lead, both of which are classified as hazardous waste within the EU. They must be removed and handled according to local regulations.</p> <p>For further information on environmental aspects and more detailed recycling instructions, contact your local ABB representative.</p>

Applicable standards

Drive compliance with the following standards is identified by the standard “marks” on the type designation label. The following standards are applicable to the drive:

Mark	Applicable standards	
	EN 50178:1997	Electronic equipment for use in power installations
	IEC/EN 60204-1:2005	Safety of machinery. Electrical equipment of machines. Part 1: General requirements. <i>Provisions for compliance</i> : The final assembler of the machine is responsible for installing: <ul style="list-style-type: none"> • an emergency-stop device • a supply disconnecting device.
	IEC/EN 60529:1989 + A1:1999 + A2:2013	Degrees of protection provided by enclosures (IP code)
	IEC 60664-1:2002	Insulation coordination for equipment within low-voltage systems. Part 1: Principles, requirements and tests
	IEC/EN 61800-5-1:2007	Adjustable speed electrical power drive systems. Part 5-1: Safety requirements. Electrical, thermal and energy
	IEC/EN 61800-3:2004 +A1:2012	Adjustable speed electrical power drive systems. Part 3: EMC requirements and specific test methods
	IEC/EN 61000-3-12:2011	Electromagnetic compatibility (EMC). Part 3-12: Limits - Limits for harmonic currents produced by equipment connected to public low-voltage systems with input current > 16 A and = 75 A per phase
	IEC/EN 61800-3:2004 +A1:2012	Adjustable speed electrical power drive systems. Part 3: EMC requirements and specific test methods
	UL 508C	UL Standard for Safety, Power Conversion Equipment, third edition
	C22.2 No. 14	CSA Standard for Industrial Control Equipment (for ACS550-U1 drives only)

Markings

CE marking



A CE mark is attached to the drive to verify that the drive follows the provisions of the European Low Voltage, EMC and RoHS Directives

Note: The 600 V ACS550-U1 drives are not CE approved.

Compliance with the European Low Voltage Directive

The compliance with the European Low Voltage Directive has been verified according to standards IEC/EN 60204-1:2005 and EN 50178:1997.

Compliance with the European EMC Directive

The Directive defines the requirements for immunity and emissions of electrical equipment used within the European Union. The EMC product standard IEC/EN 61800-3:2004 +A1:2012 covers requirements stated for drives.

Compliance with IEC/EN 61800-3:2004 +A1:2012

See page [311](#).

C-Tick marking

The drive carries C-Tick marking.

C-Tick marking is required in Australia and New Zealand. A C-Tick mark is attached to the drive to verify compliance with the relevant standard (IEC 61800-3:2004) – Adjustable speed electrical power drive systems – Part 3: EMC product standard including specific test methods), mandated by the Trans-Tasman Electromagnetic Compatibility Scheme.

The Trans-Tasman Electromagnetic Compatibility Scheme (EMCS) was introduced by the Australian Communication Authority (ACA) and the Radio Spectrum Management Group (RSM) of the New Zealand Ministry of Economic Development (NZMED) in November 2001. The aim of the scheme is to protect the radio frequency spectrum by introducing technical limits for emission from electrical/electronic products.

Compliance with IEC/EN 61800-3:004

See page [311](#).

UL/CSA markings

An UL mark is attached to ACS550 drives to verify that the drive follows the provisions of UL 508C.



A CSA mark is attached to ACS550-U1 type drives to verify that the drive follows the provisions of C22.2 NO. 14.

The ACS550 is suitable for use in a circuit capable of delivering not more than 100 kA RMS symmetrical amperes, 600 V maximum. The ampere rating is based on tests done according to UL 508.

Branch circuit protection must be provided in accordance with local codes.

The ACS550 has an electronic motor protection feature that complies with the requirements of UL 508C and, for ACS550-U1, C22.2 No. 14. When this feature is selected and properly adjusted, additional overload protection is not required unless more than one motor is connected to the drive or unless additional protection is required by applicable safety regulations. See parameters 3005 (MOT THERM PROT) and 3006 (MOT THERM RATE).

The drives are to be used in a controlled environment. See section [Ambient conditions](#) on page [307](#) for specific limits.

Note: For open type enclosures, i.e. drives without the conduit box and/or cover for IP21 / UL type 1 drives, or without the conduit plate and/or hood for IP54 / UL type 12 drives, the drive must be mounted inside an enclosure in accordance with National Electric Code and local electrical codes.

Brake choppers, when applied with appropriately sized brake resistors, will allow the drive to dissipate regenerative energy (normally associated with quickly decelerating a motor). Frame sizes R1 and R2 have a built-in brake chopper as standard

equipment. For frame sizes R3...R6, contact your local ABB representative for appropriate parts. See section [Brake components](#) on page [295](#).

EAC marking



The drive has EAC certification. EAC marking is required in Russia, Belarus and Kazakhstan.

IEC/EN 61800-3:2004 Definitions

EMC stands for **Electromagnetic Compatibility**. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

First environment includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

Second environment includes establishments connected to a network not directly supplying domestic premises.

Drive of category C2: drive of rated voltage less than 1000 V and intended to be installed and commissioned only by a professional when used in the first environment.

Note: A professional is a person or organization having necessary skills in installing and/or commissioning power drive systems, including their EMC aspects.

Category C2 has the same EMC emission limits as the earlier class first environment restricted distribution. EMC standard IEC/EN 61800-3 does not any more restrict the distribution of the drive, but the using, installation and commissioning are defined.

Drive of category C3: drive of rated voltage less than 1000 V, intended for use in the second environment and not intended for use in the first environment.

Category C3 has the same EMC emission limits as the earlier class second environment unrestricted distribution.

Compliance with the IEC/EN 61800-3:2004 +A1:2012

The immunity performance of the drive complies with the demands of IEC/EN 61800-3, category C2 (see page [311](#) for IEC/EN 61800-3 definitions). The emission limits of IEC/EN 61800-3 comply with the provisions described below.

First environment (drives of category C2)

1. The internal EMC filter is connected.
2. The motor and control cables are selected as specified in this manual.
3. The drive is installed according to the instructions given in this manual.
4. The motor cable length does not exceed the allowed maximum length specified in section [Motor cable length for 400 V drives](#) on page [290](#) for the frame size and switching frequency in use.

WARNING! In a domestic environment, this product may cause radio inference, in which case supplementary mitigation measures may be required.

Second environment (drives of category C3)

1. The internal EMC filter is connected.
2. The motor and control cables are selected as specified in this manual.
3. The drive is installed according to the instructions given in this manual.
4. The motor cable length does not exceed the allowed maximum length specified in section *Motor cable length for 400 V drives* on page 290 for the frame size and switching frequency in use.

WARNING! A drive of category C3 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.

Note: It is not allowed to install a drive with the internal EMC filter connected on IT (ungrounded) systems. The supply network becomes connected to ground potential through the EMC filter capacitors, which may cause danger or damage the drive.

Note: It is not allowed to install a drive with the internal EMC filter connected to a corner grounded TN system as this would damage the drive.

Index

Numerics

0xxxx register	
EFB function codes	218
EFB mapping	216
1xxxx register	
EFB function codes	219
EFB mapping	218
2-wire sensor/transmitter, connection example	86
3-wire macro	79
3-wire sensor/transmitter, connection example	86
3xxxx register	
EFB function codes	219
EFB mapping	219
4xxxx register	
EFB function codes	222
EFB mapping	219

A

ABB	
document library	325
feedback on ABB manuals	325
product and service inquiries	325
product training	325
standard (default) macro	78
acceleration	
/deceleration, parameter group	139
at aux. stop (PFC), parameter	200
compensation, parameter	142
ramp select, parameter	139
ramp shape, parameter	139
ramp time (PFC), parameter	200
ramp zero select, parameter	140
time, parameter	139
activate (external PID), parameter	178
actual input (PID), parameters	174
actual max. (PID), parameters	174
actual min. (PID), parameters	174
actual values	
mapping, FBA, generic profile	257
scaling, EFB comm	211
scaling, FBA comm	244
scaling, FBA, ABB drives profile	255
scaling, FBA, generic profile	257
alarm	
codes	267
codes (Basic Control Panel)	269
display enable, parameter	132
listing	267
words, data parameters	113
alternate macro	80
altitude	
derating	280
environment limit	307
shipping limit	307
ambient conditions	307
ambient temperature	
derating	280
environment limit	307
shipping limit	307
amplitude logging	
see load analyzer	
analog cable, requirements	300
analog I/O	
connections	28
specifications	28
analog input	
parameter group	123
data parameter	109
fault limit, parameters	150
filter, parameters	123
less than min. auto. reset, parameter	152
less than min., fault parameter	148
loss, fault codes	261
maximum, parameters	123
minimum, parameters	123
analog output	
parameter group	127
content max., parameters	127
content min., parameters	127
current max., parameters	127
current min., parameters	127
data content, parameters	127
data parameters	109
filter, parameters	127
obtain 0...10 V	87
analyzer, load	
see load analyzer	
angle	
mechanical, data parameter	110
application block output, data parameter	108
application macro, parameter	106
application macros	
see macros	
arrow (Assistant Control Panel)	49
assistant (Assistant Control Panel)	
start-up	57
tasks	58
Assistant Control Panel	
see control panel (Assistant)	
assistants mode (Assistant Control Panel)	57
autochange	
interval, parameter	193
level, parameter	194
overview	194
starting order counter	194
automatic reset	
see reset, automatic	
auxiliary motor	
see motor, auxiliary	

B

backing up parameters	
Assistant Control Panel	64
Basic Control Panel	75
Basic Control Panel	
see control panel (Basic)	
battery (Assistant Control Panel)	275
baud rate (RS-232), parameter	183
braking	
components	295
protection from overheated resistor	298
resistor heat dissipation	298
selecting brake choppers/resistors	295
wiring	298
break point frequency, fault parameter	149
buffer overruns (count), parameter	183

C

cable requirements	
control	299
grounding	285
input power	284
motor	292
capacitor	
reforming	275
replacement	275
category (IEC/EN 61800-3 definition)	
C2	311
C3	311
CB	
see control board	
CE marking	309
changed parameters (Assistant Control Panel)	60
chopper	
see braking	
clock	
see time and date setting (Assistant Control Panel)	
CO ₂ conversion factor	
see energy saving	
communication	
see EFB (embedded fieldbus)	
see EFB, drive parameters	
see FBA (fieldbus adapter)	
see FBA, drive parameters	
compatibility	13
conduit kit	23
config file	
CPI firmware revision, parameter	182
fault code	263
id revision, parameter	182
revision, parameter	182
connections	
control	28
diagram	28
EFB comm	204
FBA module	240
X1	28
constant speed	
see speed, constant	
construction code	17

contamination levels	
environment limit	307
shipping limit	307
contrast, control panel (Assistant)	54
control	
connection specifications	299
location, data parameter	108
terminal specifications	300
through I/O interface	44
control board	
overtemperature, fault code	264
overtemperature, fault parameter	151
temperature, data parameter	110
control cable	
connections	28
requirements	299
control panel	47
cable requirements	300
comm error, fault parameter	148
display bar-graph	156, 157
display decimal point (form), parameters	156
display max., parameters	157
display min., parameters	157
display process variables, parameter group	156
display selection, parameters	156
display units, parameters	157
maintenance	275
manual compatibility	47
parameter lock, parameter	129
pass code, parameter	129
reference control, parameter	117
signal max., parameters	156
signal min., parameters	156
control panel (Assistant)	48
arrow	49
assistants mode	57
battery	275
changed parameters mode	60
direction of rotation	49, 53
display contrast	54
fault logger mode	61
fault mode	49, 259, 260
help	51
how to do common tasks	50
I/O settings mode	67
main menu	50
operation	49
output mode	53
overview	48
parameter backup mode	64
parameters mode	55
soft keys	48
start/stop	52
status line (LOC/REM, arrow)	49
time and date mode	62

control panel (Basic)	68
alarm codes.	269
copy mode.	75
direction of rotation	68, 70
fault mode	69, 259, 260
how to do common tasks	69
main menu	69
operation	69
output mode	71
overview	68
parameter mode	73
reference mode	72
start/stop	70
control word	
ABB drives, FBA, description	248
EFB, description	224
FBA	238
FBA generic profile	256
cooling	
air flow.	301
fan maintenance triggers	147
heat dissipation	301
space requirement	301
copy mode (Basic Control Panel)	75
corner grounded TN system	285
warning about filters	6
warning about screws at EM1, EM3	25
warning about screws at F1, F2	26
correction source (PID), parameter	179
cover	
remove	21
replace	36
cover, top, see hood	
CRC errors (count), parameter	183
crimp-on ring lugs	287
critical speeds (avoiding)	
parameter group	144
high, parameters	144
low, parameters	144
select, parameter	144
C-Tick marking	310
current	
at fault, history parameter	114
data parameter	108
max. limit, parameter	133
measurement, fault code	262
rating code	17
D	
date	
see time and date setting (Assistant Control Panel)	
DC	
brake time, parameter	137
bus voltage, data parameter	108
current ref., parameter	137
magnetizing time, parameter	136
overvoltage, fault code	261
undervoltage, fault code	261
voltage stabilizer, parameter	146
E	
EAC marking	311
deceleration	
parameter group	139
at aux. start (PFC), parameter	200
emergency time, parameter	140
ramp select, parameter	139
ramp shape, parameter	139
ramp time (PFC), parameter	200
ramp zero select, parameter	140
time, parameter	139
default values	
listing for macros	89
listing for parameters	91
derating	
adjustment example	280
altitude	280
single phase supply	280
switching frequency	280
temperature	280
derivation time (PID), parameter	171
derivation time, parameter	141
device overtemperature, fault code	261
diagnostics	259
EFB comm	212
FBA comm	245
digital cable requirements	300
digital input	
at fault, history parameters	114
connections	28
specifications	29
status, data parameter	109
digital output	
connections	28
specifications	299
dimensions	
drive, mounting	303
drive, outside	304
DIP switches	25, 28
direction control, parameter	116
direction of rotation	
Assistant Control Panel	49, 53
Basic Control Panel	68, 70
display format (PID), parameter	171
disposal	308
document library	325
download parameter sets	
application	64
full set	64
user sets	64
drive	
EFB comm installation	204
FBA module installation	240
id, fault code	263
mounting	22
mounting dimensions	303
outside dimensions	304
rating, parameter	155
temperature, data parameter	108
weight	306
drive on time, data parameters	110

earth fault	300
detection level	151
fault code	262
parameter	150
earthing	
see ground	
EFB (embedded fieldbus)	203
actual value scaling	211
actual values	211
analog output control, activate	209
comm fault response	210
configuration	206
configure for loss of communication	213
control interface	203
control word	224
diagnostics	212
drive control of functions, activate	207
exception codes	223
fault code 28	214
fault code 31	214
fault code 32	214
fault code 33	214
fault tracing parameters	212
fault, duplicate stations	213
fault, intermittent off-line	214
fault, no master station on line	213
fault, swapped wires	213
feedback from drive	211
input reference sel., activate	208
installation	204
misc. drive control, activate	208
modbus actual values	223
PID control setpoint source, activate	210
planning	204
profiles	216
reference scaling, ABB drives profile	233
reference scaling, DCU profile	233
relay output control, activate	209
set-up	205
start/stop/direction control, activate	207
state diagram	232
status word	227
termination	205
EFB, drive parameters	184
protocol, parameter group	184
baud rate, parameter	184
command words, data parameters	112
config file, fault code	263
control profile, parameter	184
CRC errors (count), parameter	184
fault codes	263
fault function, parameter	150
fault time, parameter	150
ok messages (count), parameter	184
parameters	184, 185
parity, parameter	184
protocol id, parameter	184
protocol select, parameter	201
relay output word, data parameter	109
station id, parameter	184
status words, data parameters	112
status, parameter	184
UART errors (count), parameter	184
values, data parameter	109
efficiency	300
ELV (Extra Low Voltage)	29
EM1 and EM3 screws	
location	25
on corner grounded TN system	27
on IT systems	27
on symmetrically grounded TN systems	27
warning	25, 285, 286
embedded fieldbus	
see EFB	
see EFB, drive parameters	
EMC	
CE marking	309
C-Tick marking	310
motor cable requirements	293
EMC filter, external	286
EMC filter, internal	27, 285, 286, 311, 312
emergency	
deceleration time, parameter	140
stop devices	283
stop select, parameter	137
enclosure	
protection class code	17
types	306
encoder	
parameter group	181
enable, parameter	181
error, fault code	263
fault, parameter	181
number of pulses, parameter	181
position reset enable, parameter	181
zero pulse detected, data parameter	110
zero pulse enable, parameter	181
energy saving	
parameter group	180
CO2 conversion factor, parameter	180
energy price, parameter	180
energy reset, parameter	180
pump power, parameter	180
saved amount 1, data parameter	111
saved amount 2, data parameter	111
saved CO2, data parameter	111
saved kWh, data parameter	111
saved MWh, data parameter	111
error value inversion (PID), parameter	171
exception codes, EFB modbus	223
external comm module, parameter group	
see FBA, drive parameters	
external commands selection, parameter	115
external control selection, parameter	117
external fault	
automatic reset, parameter	152
fault codes	262
parameters	148
external reference, data parameter	108

F

F1 and F2 screws	
location	26
on corner grounded TN system	27
on IT systems	27
on symmetrically grounded TN systems	27
warning	26, 285, 286
fan	
control	132
maintenance	272, 274
fault	
functions, parameter group	148
history, parameter group	114
codes	260
comm failure (EFB)	210
current at, history parameter	114
digital input status at, history parameter	114
FBA comm	244
frequency at, history parameter	114
history	266
last, history parameter	114
listing	260
logging (Assistant Control Panel)	61
mode (Assistant Control Panel)	49, 259, 260
mode (Basic Control Panel)	69, 259, 260
previous, history parameter	114
reset	132, 265
reset select, parameter	129
speed at, history parameter	114
status at, history parameter	114
time of, history parameters	114
torque at, history parameter	114
voltage at, history parameter	114
words, data parameters	113
fault display	
alarm	260
fault	259
fault names	260
FB actual signals, parameter group	112
FBA	
protocol listing	237
FBA (fieldbus adapter)	237
actual values	239
analog output control, activate	243
comm fault response	244
configuration	241
control word	238
control word, ABB drives	248
diagnostics	245
drive feedback	244
fieldbus control, activate	241
input reference sel., activate	242
installation	240
PID control setpoint source, activate	244
planning	239
reference	239
relay output control, activate	243
set-up	241
start/stop /direction control, activate	241
state diagram, ABB drives	251
status word	239
status word, ABB drives	249
FBA, drive parameters	182
ext comm module parameter group	182
command words, data parameters	112
config file CPI firmware revision, parameter	182
config file id revision, parameter	182
config file revision, parameter	182
fault function, parameter	150
fault time, parameter	150
fieldbus appl. program revision, parameter	182
fieldbus CPI firmware revision, parameter	182
fieldbus parameter refresh, parameter	182
fieldbus parameters	182
fieldbus status, parameter	182
fieldbus type, parameter	182
protocol select, parameter	201
relay output word, data parameter	109
status words, data parameters	112
values, data parameter	109
feedback	
multiplier (PID), parameter	173
on ABB manuals	325
select (PID), parameter	173
field weakening point	289
fieldbus	
see EFB (embedded fieldbus)	
see EFB, drive parameters	
see FBA (fieldbus adapter)	
see FBA, drive parameters	
fieldbus adapter	
see FBA	
see FBA, drive parameters	
fieldbus, embedded	
see EFB	
see EFB, drive parameters	
firmware	
compatibility	13
panel, version	47, 51
version, parameter	66, 155
first environment	
(C2), compliance with IEC/EN 61800-3	311
(C2), motor cable length	290
definition	311
flange mounting	20
FlashDrop	
application macro, parameter	106
connection	25
parameter view, parameter	132
floating network	
see IT system	
flux braking, parameter	145
flux optimization, parameter	145
force trip, fault code	263
frame errors (count), parameter	183
frame size	277
free fall, stress testing	307
frequency	
at fault, history parameter	114
max. limit, parameter	134
min. limit, parameter	134
motor, resolution	289
motor, specification	289
switching, parameter	146

fuses	
208...240 V drives	282
380...480 V drives	282
500...600 V drives	283
 G	
gain (PID), parameter	170
generic profile, FBA	
actual value mapping	257
actual value scaling	257
overview	256
reference scaling	256
technical data	256
gland kit	23
ground	
cable/wire requirements	285
fault protection	292
 H	
hand-auto macro	82
heat dissipation	301
hood (IP54 / UL type 12)	21, 36
how to do common tasks	
with Assistant Control Panel	50
with Basic Control Panel	69
 I	
I/O settings (Assistant Control Panel)	67
I/O, control through	44
id run	
fail, fault code	262
parameter	107
performing	45
identification magnetization	107
IEC ratings	
see ratings	
impedance grounded network	
see IT system	
incompatible software, fault code	264
information on the Internet	325
information, parameter group	155
input power	
cable/wire requirements	284
disconnecting device (disconnecting means)	281
specifications	281
input power connection	
IT system	286
lugs for R6	287
terminal size	286
torque	286
installation	
check list	35
compatibility	18
environment	18
flow chart	15
location	19
mounting drive	22
preparation	16
procedures	15
tools	18
wiring overview	23
insulation check	30
integration time (PID), parameter	171
integration time, parameter	141
interlocks, parameter	195
internal setpoint (PID), parameter	173
Internet, information on	325
IR compensation	
frequency, parameter	145
parameters	145
voltage, parameter	145
isolation, between AC power source and drive	281
IT system	
connections	286
warning about filters	6, 294
warning about screws at EM1, EM3	25
warning about screws at F1, F2	26
 J	
jogging activation, parameter	116
 K	
keypad	
see control panel	
keypad reference select, parameter	117
kWh	
counter, data parameter	108
 L	
label	
serial number	16
type designation	16
language, parameter	106
LED	
on Assistant Control Panel	48, 259, 260
on drive body	25, 259, 260
library, document	325
limits, parameter group	133
load analyzer	
parameter group	186
amplitude logger 1, distribution	187
amplitude logger 2 signal base value, par...	186
amplitude logger 2 signal, parameter	186
amplitude logger 2, distribution	187
loggers reset date	187
loggers reset time	187
loggers reset, parameter	186
peak value logger filter time, parameter	186
peak value logger signal, parameter	186
peak value logger, current at peak value	187
peak value logger, detected peak value	186
peak value logger, frequency at peak value	187
peak value logger, peak value date	186
peak value logger, peak value time	186
peak value logger, voltage at peak value	187
load curve, see user load curve	
load frequency, see user load curve	
load torque, see user load curve	
loading package version, parameter	155
LOC (local control)	
indication on Assistant Control Panel	49
indication on Basic Control Panel	68

local control mode lock, parameter	130
lock	
control panel access, IP54	36
drive control at local control panel.	130
parameters	129
loggers	
see load analyzer	
low frequency (PFC), parameters	191
lugs	
for R6 power cables	287
ring, crimp-on	287
terminal, screw-on.	288
M	
macros	
3-wire	79
ABB standard (default)	78
alternate	80
hand-auto	82
motor potentiometer	81
PFC.....	84
PID control	83
torque control	85
user parameter sets	88
parameter default values.....	89
parameters not changed.....	77
magnetization, identification	107
main menu	
Assistant Control Panel.....	50
Basic Control Panel.....	69
mains	
see input power	
maintenance	
capacitors	275
control panel	275
heat sink	271
internal enclosure fan	274
intervals.....	271
main fan	272
triggers, parameter group	147
manuals	
list of ACS550 manuals.....	2
providing feedback	325
mapping	
actual value, FBA, generic profile	257
EFB modbus	216
materials	308
maximum	
frequency, parameter	134
torque limit, parameters	135
torque select, parameter	134
mechanical	
angle, data parameter	110
revolutions, data parameter	110
minimum	
frequency, parameter	134
torque limit, parameters	134
torque select, parameter	134
modbus	
EFB addressing, convention	216
EFB coils	216
EFB discrete inputs	218
EFB holding registers.....	219
EFB input registers.....	219
EFB mapping details	216
EFB mapping summary	216
EFB supported features	215
EFB technical data.....	215
motor	
checking insulation.....	30
compatibility	18
id run, parameter	107
load curve break point frequency	149
load curve max., fault parameter	149
load curve zero speed load	149
maintenance triggers	147
nominal current, parameter	107
nominal frequency, parameter	107
nominal power, parameter	107
nominal speed, parameter	107
nominal voltage, parameter	107
phase, fault code	263
requirements	18
stall, fault code	262
thermal protection.....	291
motor cable	
checking insulation.....	30
length	289
max. length.....	289
requirements	292
requirements, EMC	293
motor connection	
lugs for R6	287
terminal size	286
torque	286
motor control	
parameter group	145
control mode, parameter	106
IR compensation, parameters	145
motor potentiometer macro.....	81
motor temperature	
measure, parameter group	159
alarm limit, parameter	160
data parameter	110
fault limit, parameter	161
overtemperature, fault code	261
sensor selection, parameter	160
sensor type, parameter	160
thermal protection.....	291
thermal protection, fault parameter	148
thermal stress, data parameter	111
thermal time, fault parameter	149
motor, auxiliary	
aux start order, parameter	200
aux. start delay (PFC), parameter	191
aux. stop delay (PFC), parameter	191
number of aux., parameter	192
motors	
several	279, 289

mounting	
dimensions	303
flange	20
template	20
multimotor systems	136, 146, 279, 289
MWh	
counter, data parameter	110
power consumption, maintenance trigger..	147

N

NEMA ratings	
see ratings	
noise	301
random sw. freq. parameter	146
NPN.....	29

O

offset (PID), parameter	178
ok messages (count), parameter.....	183
operating data, parameter group.....	108
operation	
Assistant Control Panel	49
Basic Control Panel	69
OPEX link, fault code	262
OPEX power, fault code	262
options.....	17
parameter group	201
code	17
output	
frequency, data parameter	108
voltage, data parameter	108
wiring, fault code.....	263
output mode	
Assistant Control Panel	53
Basic Control Panel	71
overcurrent	
automatic reset, parameter.....	152
fault code	260
overload curve	
see user load curve	
overmodulation	146
overspeed, fault code	263
overvoltage	
control enable, parameter.....	133

P

panel communication, parameter group	183
panel display variables, parameter group	156
panel firmware version	47, 51
panel loss, fault code.....	261

parameter	
analog input scale, fault code.....	264
analog output scale, fault code	264
change lock	129
descriptions	106
external relay output, fault code	265
fieldbus, fault code	265
hz rpm, fault code.....	264
listing (ranges, resolutions, defaults)	91
PCU 1 (power control unit), fault code	265
PCU 2 (power control unit), fault code	265
PFC IO, fault code	265
PFC mode, fault code	265
PFC ref. neg., fault code	264
save changes	130
table version, parameter	155
user load curve, fault code.....	265
view, parameter	132
parameter mode	
Assistant Control Panel	55
Basic Control Panel	73
parameter restore	
Assistant Control Panel	64
Basic Control Panel	75
parity	
(RS-232), parameter	183
errors (count), parameter	183
PE earth	
earth fault, parameter	150
PE earth connection	
terminal size	286
torque	286
peak value logging	
see load analyzer	
PELV (Protective Extra Low Voltage).....	29
PFC	
control, parameter group	189
acceleration time, parameter	200
aux start order, parameter	200
aux. motor start delay, parameter	191
aux. motor stop delay, parameter	191
deceleration time, parameter	200
enable, parameter	199
low frequency, parameters.....	191
macro	84
number of aux. motors, parameter.....	192
number of motors parameter	200
reference step, parameters	189
start delay, parameter	199
start frequency, parameters	190

PID	
process sets, parameter groups	169
external / trimming, parameter group	178
0% (actual signal), parameter	172
100% (actual signal), parameter	172
actual input select, parameters	174
actual value max., parameters	174
actual value min., parameters	174
adjustment procedure	170
comm value 1, data parameter	111
comm value 2, data parameter	111
control macro	83
correction source, parameter	179
decimal point (actual signal), parameter	171
derivation filter, parameter	171
derivation time, parameter	171
deviation, data parameter	109
error feedback inversion, parameter	171
external source activate, parameter	178
feedback multiplier, parameter	173
feedback select, parameter	173
feedback, data parameter	109
gain, parameter	170
integration time, parameter	171
internal setpoint, parameter	173
offset, parameter	178
output, data parameter	109
parameter set select, parameter	176
scaling (0...100%), parameters	172
setpoint maximum, parameter	173
setpoint minimum, parameter	173
setpoint select, parameter	172
setpoint source, EFB comm activate	210
setpoint source, FBA comm, activate	244
setpoint, data parameter	109
sleep delay, parameter	175
sleep level, parameter	175
sleep selection, parameter	174
trim mode, parameter	178
trim scale, parameter	178
units (actual signal), parameter	171
wake-up delay, parameter	175
wake-up deviation, parameter	175
PID controller	
advanced set-up	170
basic set-up	169
planning	
EFB comm	204
FBA comm	239
PNP	
power	
consumption (MWh) maintenance trigger	147
data parameter	108
previous faults, history parameters	114
process PID sets, parameter groups	169
process variables, data parameter	110
product	
inquiries	325
training	325
profiles, EFB comm	216
proportional gain, parameter	141
protection	
circuit, required w/ chopper	298
disconnecting device (disconnecting means)	281
enclosure standard	309
environmental	306
motor thermal	291
PT100 temperature sensor	160
PTC temperature sensor	160
pump power	
see energy saving	
R	
radiation limits, conducted	
EN 61800-3	294
ramp pair (accel/decel), parameter	139
range listing for parameters	91
ratings	277
reference	
select, parameter group	117
corrections for parameter values	118
keypad control, parameter	117
maximum, parameters	119
minimum, parameters	119
mode (Basic Control Panel)	72
select source, parameter	117
step (PFC), parameters	189
reference scaling	
EFB, ABB Drives profile	233
EFB, DCU profile	233
FBA, ABB drives profile	252
FBA, generic profile	256
reference setting	
Assistant Control Panel	54
Basic Control Panel	72
regulator by-pass control, parameter	199
relative humidity	
environment limit	307
shipping limit	307
relay output	
parameter group	124
activation condition parameters	124
off-delay, parameters	125
on-delay, parameters	125
status, data parameter	109
relays, specifications	299
REM (remote control)	
indication on Assistant Control Panel	49
indication on Basic Control Panel	68
remove cover	21
reset, automatic	
parameter group	152
analog input less than min., parameter	152
delay time, parameter	152
external fault, parameter	152
number of trials, parameter	152
overcurrent, parameter	152
trial time, parameter	152
undervoltage, parameter	152
resolution listing for parameters	91
resonance (avoiding)	
select, parameter	144
revolution counter, data parameter	110

revolutions, mechanical, data parameter	110	specifications	
ring lugs.	287	control connections	299
RS-232		input power.	281
baud rate, parameter	183	mains	281
parity, parameter	183	speed	
station id, parameter	183	and direction (signed), data parameter	108
RS-232 counts		at fault, history parameter	114
buffer overruns, parameter	183	data parameter.	108
CRC errors, parameter	183	max. limit, parameter	133
frame errors, parameter	183	min. limit, parameter	133
ok messages, parameter	183	speed control	
parity errors, parameter	183	parameter group.	141
RS485 comm.	204	acceleration compensation, parameter	142
run enable source select, parameter	129	automatic tuning, parameter	141, 142
run time		derivation time, parameter	141
data parameter	108, 110	integration time, parameter	141
maintenance trigger	147	proportional gain, parameter	141
S		vector:speed mode.	106
safety.	5	speed, constant	
save changes parameter.	130	parameter group.	120
saving, energy		digital input selection parameter	120
see energy saving		parameters.	121
scalar:frequency mode	106	stall	
scaling		frequency, fault parameter	150
actual value, FBA, ABB drives profile	255	function, fault parameter	150
actual value, FBA, generic profile	257	region	150
actual values, EFB comm	211	time, fault parameter	150
reference, EFB, ABB drives profile	233	standards	309
reference, EFB, DCU profile	233	C22.2 No. 14	309
reference, FBA, ABB drives profile	252	CE marking	309
reference, FBA, generic profile	256	CSA marking	310
screw-on terminal lugs	288	C-Tick marking	310
s-curve ramp, parameter	139	EN 50178	309
second environment		IEC 60664-1	309
(C3), compliance with IEC/EN 61800-3	312	IEC/EN 60204-1	309
(C3), motor cable length	290	IEC/EN 60529	309
definition	311	IEC/EN 61000-3-12	309
sensor type, parameter	160	IEC/EN 61800-3	309
sensorless vector control mode.	106	IEC/EN 61800-5-1	309
serial 1 error (fault code 28)	214	UL 508C	309
serial 1 error, fault code.	263	UL marking.	310
serial communication		start	
see EFB (embedded fieldbus)		parameter group.	136
see EFB, drive parameters		aux. motor (PFC), parameters	190
see FBA (fieldbus adapter)		aux. motor delay.	191
see FBA, drive parameters		control, EFB comm.	207
serial number.	16, 17	control, FBA comm.	241
service.	325	DC magnetizing time, parameter	136
setpoint maximum (PID), parameter	173	delay (PFC), parameter	199
setpoint minimum (PID), parameter	173	delay, parameter	138
setpoint select (PID), parameter	172	frequency (PFC), parameters.	190
shock, stress testing	307	function, parameter	136
short circuit, fault code	261	inhibit, parameter	137
single phase supply		select enable source, parameter	131
connection	23	torque boost current, parameter.	137
derating.	280	start mode	
sleep selection (PID), parameter.	174	automatic	136
slip compensation ratio, parameter.	146	automatic torque boost.	136
soft keys (Assistant Control Panel)	48	DC magnetizing	136
		flying start.	136
		start/stop	
		parameter group.	136
		with Assistant Control Panel	52
		with Basic Control Panel	70

start/stop/dir, parameter group	115
starting order counter	194
start-up	
assistant	42, 57
data, parameter group	106
guided, Assistant Control Panel	42
limited, Assistant or Basic Control Panel	37
state diagram	
comm (EFB)	232
comm, ABB drives	251
station id (RS-232), parameter	183
status at fault, history parameter	114
status word	
ABB drives, FBA, description	249
EFB comm, definition	227
FBA	239
FBA generic profile	256
stop	
parameter group	136
aux. motor (PFC), parameters	191
aux. motor delay	191
DC brake time, parameter	137
DC current control, parameter	136
DC current ref., parameter	137
emergency devices	283
emergency select, parameter	137
flux braking, parameter	145
function, parameter	136
stress tests	307
supervision	
parameter group	153
parameter low limit, parameters	153
parameter selection, parameters	153
supply cable	
checking insulation	30
supply phase, fault code	262
switching frequency	289
control, parameter	146
derating	280
parameter	146
symmetrically grounded network	
see corner grounded TN system	
symmetrically grounded TN system	285
system controls, parameter group	129
T	
temperature derating	280
template, mounting	20
terminal lugs	288
terminals	
control, description	28
control, specifications	300
location diagram, R1...R4	25
location diagram, R5/R6	26
termination	205
test date, parameter	155
thermal fail, fault code	262
three-wire sensor/transmitter, connection example	86
time and date setting (Assistant Control Panel)	62
timed functions	
parameter group	162
autochange, parameter	200
booster, parameter	164
enable, parameter	163
source, parameter	164
speed control	122
start time, parameter	163
stop time, parameter	163
timed mode, parameter	122
TN-S system	285
tools	18
top cover, see hood	
torque	
at fault, history parameter	114
boost current, parameter	137
data parameter	108
max. limit select, parameter	134
max. limit, parameter	135
min. limit select, parameter	134
min. limit, parameters	134
ramp down, parameter	143
ramp up, parameter	143
torque control	
parameter group	143
macro	85
ramp down, parameter	143
ramp up, parameter	143
vector:torque mode	106
training	325
trim	
mode (PID), parameter	178
scale (PID), parameter	178
two-wire sensor/transmitter, connection example	86
type code	
see type designation	
type designation	16, 17
U	
U/f ratio, parameter	145
UL/CSA markings	310
underload curve	
see user load curve	
undervoltage	
automatic reset, parameter	152
control enable, parameter	133
ungrounded network	
see IT system	
units (PID), parameter	171
unknown drive type, fault code	264
unpacking drive	16
unsymmetrically grounded networks	
see corner grounded TN system	
user load curve	
parameter group	166
fault code	264
frequency, parameters	166, 167
function, parameter	166
mode, parameter	166
time, parameter	166
torque, parameters	166, 167

user parameter set	88
change control, parameter	130
download	64

V

vector:	
speed mode	106
torque mode	106
version	
firmware	13
firmware, parameter	66, 155
loading package, parameter	155
panel firmware	47, 51
parameter table, parameter	155
vibration, stress testing	307
voltage	
at fault, history parameter	114
rating code	17
voltage/frequency ratio, parameter	145

W

wake-up	
delay (PID), parameter	175
deviation (PID), parameter	175
warning	
automatic start up	7
dangerous voltages	5, 6
disconnecting device (disconnecting means)	7
ELV (Extra Low Voltage)	29
EM1, EM3, F1 and F2 screws	6
filter on corner grounded TN system	6
filter on IT system	6
high temperatures	5
listing	5
not field repairable	5, 6
parallel control connections	6
qualified installer	5
weight	306
wiring	
control	28
fault, parameter	151
installation	30
installation steps, IP21/cables	30
installation steps, IP21/conduit	32
installation steps, IP54/cables	33
installation steps, IP54/conduit	34
overview	23
requirements, general	23

XYZ

zero pulse	
detected, data parameter	110
enable, parameter	181
zero speed	
delay, parameter	138
load, fault parameter	149

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to www.abb.com/drives and select *Training courses*.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Go to www.abb.com/drives and select *Document Library – Manuals feedback form (LV AC drives)*.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet. Go to www.abb.com/drives and select *Document Library*. You can browse the library or enter selection criteria, for example a document code, in the search field.

Contact us

www.abb.com/drives

www.abb.com/drivespartners

3AFE64804588 (3AUA0000001418) Rev H / EN

EFFECTIVE: 2014-07-04

SUPERSEDES: 3AFE64804588 (3AUA0000001418) Rev G 2009-07-07



3AFE64804588_3AUA0000001418_H